



## How to dismount the Lens Hood:


The 1.8X lens comes with a Lens Hood mounted and it is recommended to use the lens as it is without detaching the Hood. When you want to dismount the Hood for some specific reasons, place the lens on a firm standing area, and turn the Hood anti-clockwise with a palm of your hand. See diagram (A). Or, turn the Hood anti-clockwise with two hands while pressing slightly like shown in the diagram (B). It's not easy to dismount the Hood by one hand giving some pressure on the barrel. See the diagram (C).



(A) Turn the Hood anti-clockwise with a palm of your hand.



(B) Turn the Hood anti-clockwise with two hands while pressing slightly like shown in the diagram.




(C) It's not easy to dismount the Hood by one hand giving some pressure on the barrel.

## レンズフードの取り外し方

1.8X望遠レンズには工場出荷時にレンズフードが装着されています。通常そのまま撮影されることをお勧めします。レンズ表面清掃などの目的でレンズフードを取り外す場合はレンズを固定した安全な場所で下記イメージA)手のひらをフード全体にあて反時計方向に回す。またはイメージB)レンズフードのふちを両手でつかみ反時計方向に回す。の各方法で取りはずすことができます。


\*レンズフード外側から押さえて(イメージC)フードを取り外すことは困難です。

イメージA)




A)手のひらをフード全体にあて反時計方向に回す。

イメージB)



B)レンズフードのふちを両手でつかみ反時計方向に回す。

イメージC)



\*レンズフード外側から押さえてフードを取り外すことは困難です。